
Sisal Mat Scratch Perch CM-0262


08/16/17 V1



DO NOT RETURN THIS UNIT Please make sure you have all parts prior to assembly. All SportPet® products include a 6-month limited manufacturer's warranty for defective or missing parts. If any parts are missing or damaged, Please email our friendly customer service center at info@sportpet.net


Step 1

Attach Feet (E) to bottom of Base Halves (G) placing them EXACTLY as shown below to ensure maximum stability of item. Then connect base halves by inserting **Dowels (D)** into side holes.




Step 2

Attach base to **Post (F)**. Screw **Bolts (B)** through **Washers (C)** into bottom holes of the base using **Wrench (A)** as shown below.



Step 3

Attach Platform (H) to opposite end of Post (F). Screw Bolt (B) into top hole of the platform using Wrench (A) as shown below.



Step 4

Stretch elastic of **Fleece Cover with Toy (J)** over top platform of item as shown below. Item is now complete.



Λ

Because every cat is different, it is important to monitor your cat's behavior with this product. If at anytime your cat damages this item, or any portion of this item becomes damaged, remove the damaged portion or discontinue use of the product.