


**DO NOT RETURN THIS UNIT** Please make sure you have all parts prior to assembly. All SportPet® products include a 6-month limited manufacturer's warranty for defective or missing parts. If any parts are missing or damaged, Please email our friendly customer service center at info@sportpet.com

## Step 1


Pull Rectangular Base (A) panels away from each other to create a rectangular base. Place Platform (B) inside Rectangular Base (A).






#### Step 3

Connect **Tunnel Pieces (F&G)** together, one side at a time, with hook & loop tabs facing outwards, by inserting **Connectors (E)** through small holes in the tunnel fabric and locking together to form a round tunnel.




#### Step 4

Attach Completed Tunnel (F&G) to Rectangular Base (A) using hook & loops strips. Then place Rectangular Lid (D) with textured fabric side facing up and solid gray fabric facing down (as shown below) on top of Rectangular Base (A).




### Step 5

Place Cube (H) into Rectangular Lid (D). Cube can go on either side of the Rectangular Lid. Then place Platform (J) inside Cube (H).




#### Step 6

Place **Cube Lid (K)** with textured fabric side facing up and solid gray fabric facing down on top of **Cube (H)**.



# Step 7 Place Cushion (L) inside top of Cube Lid (K) and place Scratch Board (M) inside top of Rectangular Lid (D).



# Platforms (B&J) and Cushion (L) Washing Instructions



Remove boards from **Platform (B&J)** covers.

Machine Wash on COLD/COLD using GENTLE cycle. Machine Dry on LOW heat or AIR DRY



Platform (B&J) covers and Cushion (L) are machine washable and dryer safe.

