

# Swat Track and Scratcher

THIS UNIT CONTAINS:




**P x 1**  
(20101)




**Q x 4**  
(10210)



**U x 1**  
(20102)



Follow these instructions when attaching to other Kitty City™ units.



## DO NOT RETURN THIS UNIT TO THE STORE

Please make sure you have all parts prior to assembly. If any parts are missing or damaged, Please contact our friendly customer service center TOLL FREE: 1-866-818-2261 or [info@sportpet.net](mailto:info@sportpet.net) (Monday through Friday 8:30am - 5:00pm CST)

Visit us on the web! [www.kittycityusa.com](http://www.kittycityusa.com)



Because every pet is different, it is important to monitor your pet's behavior with this product. If at anytime your pet damages this item, or any portion of this item becomes damaged, remove the damaged portion or discontinue use of the product.